Mobile Digital Video Recorder

User's Manual

Thank you for using our Mobile DVR. This manual is applicable for ZDDV-C304 series. Please read this User's Manual carefully to ensure that you can use the device correctly and safely. The contents of this manual are subject to be changed without notice.

Warning

This device is NOT of waterproof; to prevent it from any accident of fire or electric shock, please do NOT put any container with water on the device or nearby. Do not expose the device to moisture, or extreme temperatures.

This lightning flash with arrow symbol within an equilateral triangle is intended to alert users that there might be uninsulated dangerous voltage which may cause electric shock to person when the cover of device is opened.

CAUTION

RISK OF ELECTRIC SHOCK

DO NOT OPEN

To prevent from the risk of electric shock, do NOT remove top cover or back cover. There is NO user-serviceable part inside. Ask for service from qualified maintenance man.

The exclamation point within an equilateral triangle is intended to alert users the important operating and maintenance(servicing) instructions in this manual.

Important notice:

1. Please read over all cautions.
2. Please keep this manual for reference in the future.
3. Please notice all warning information.
4. Please strictly follow the instructions in this manual while operating.
5. Please NEVER put this device under the place which is easily poured by water.
6. Please do NOT use abrasive chemicals, cleaning solvents or strong detergents to clean the device. Wipe the device with a soft and dry cloth.
7. Please do NOT get the gate of airiness heat exchange closed.
8. Please leave the device far away from hot and high temperature environment.
9. Install the device with the accessories coming with it.
10. Please take care when moving the device, make sure of security, and avoid being damaged by dropping from high place.
11. Call for qualified maintenance man to repair when needed.
12. The device can only be installed horizontally. Installed vertically or out of the horizontal could hurt person or damage the device or/and its parts.

Table of Contents

Main Features 4
Front Panel 5
Rear Panel ZDDV-C304 6
Remote Controller 7
Record to Hard Drive 8
Step 1, install the hard drive into the hard drive case 8
Step 2, Connecting to power supply 10
Step 3, Connecting to camera 11
Step 4, Turn on the recorder 11
Step 5, Format the hard drive 11
Step 6, Choose video quality 11
Step 7, Record to hard drive 12
Step 8, Install the monuting bracket 12
Play back recorded file on Hard Drive 14
How to copy from Hard Drive to Compact Flash 16
Record to Compact Flash 17
Using the Menu 18
Using Alarm and Sensor 20
Using Pre and Post Recording 23
Record to hard drive continuously and record to Compact Flash in alarm mode 24
Schedule the recording 25
Start recording when unit is powered on 25
Start and Stop recording at a specified time every day 26
Start and Stop recording at a specified date weekly 27
Vehicle Setup 29
Set the vehicle ID and route information 29
Get speed from GPS 29
Get Speed from Speedometer 30
Manage the power 33
Use the ignition to control the power 33
Turn on/off the DVR automatically 34
Set Date and Time 35
Using Pan/Tilt/Zoom 36
Manage the configuration 37
Export the configuration 37
Reset Defaults 37
Update the firmware 38
Using GPRS 39
Cable Description 42
Specification 45
List of Standard Accessories 46

Main Features

Video and audio

- MPEG2 compression, real time recording (25 fps for PAL and 30 fps for NTSC).
- DVD (Full D1, 704x576) resolution for one channel recording, VCD (CIF, 352x288) for 4 channels recording.
- Support 4 channels video and 2 channels audio recording.

Power input

- Support from +8V DC to +32VDC. Applicable for vehicles with +12V or +24V battery.
- When the power input connects in reverse polarity, the auto-protect function can prevent the recorder and battery from damage.
- The recorder provides each camera with stable +12V DC power; DVR can detect the short cut on power circuit.
- Can use ignition to control the power.

Recording mode

- Continuous record.
- Start recording automatically when the DVR is turned on.
- Support schedule recording.
- Support alarm recording.

Shock mount

- Suspending shock mount for hard drive; High reliable hard drive connector.
- Suspending shock mount for DVR.

Hard Drive

- Removable hard drive, supports standard 2.5 inch hard drive for laptop.
- FAT32 Compatible file system.
- Specifically designed file system for mobile use.

Speed and Vehicle status recording

- Record vehicle speed and car id with audio and video.
- Support 6 sensors, can be connected to brake, return, right turn, left turn light etc.
- Over-speed alarm.

Front Panel



①：LAN Port (RJ45)
②：Power Indicator Light
③：Running Indicator Light
④：Alarm Indicator Light
⑤：Hard Drive Indicator Light
⑥：Compact Flash Indicator Light
⑦：External IR Connector
⑧：Compact Flash Slot
⑨：Power Switch

Get to know the status of Mobile DVR by the indication of PWR light and RUN light:

PWR	RUN	Description
Always On	Blinking	DVR is turned on and running.
Blinking with RUN by turns	Blinking with PWR by turns	Ignition is not enabled and DVR is turned off.
Blinking together with RUN	Blinking together with PWR	Ignition is not enabled and DVR is running. The DVR will be turned off when it reached the "Ignition Power Off Delay" time.
Blinking	Off	The DVR is turned off. It will restart if POWER button is pressed on the remote.

Rear Panel (ZDDV-C304)



①：Power input
②：J1 cable (integration cable) connector
③：J2 cable (A/V cable) connector

Remote Controller



1. Power
2. Stop
3. Record
4. Alarm
5. Play
6. Numbers
7. Audio
8. Video
9. Up
10. Left
11. Right
12. Menu
13. ESC
14. OK
15. Down
16. Fast Forward
17. Pause/Step
18. Fast Backward
19. OSD
20. Next
21. Previous

Record to Hard Drive

Step 1, install the hard drive into the hard drive case

To Install hard drive with SATA interface, please do as following steps.

1. Remove screws on the back side of the hard drive case.

2. Take the SATA connector out of the hard drive case.



3. Connect the connector with the hard drive.

4. Put the hard drive back to the hard drive case. Please note, the hard drive should be put to the mounting bracket inside of the hard drive case.

5. Install the hard drive with mounting bracket though the holes on the hard drive case. Please note, install the hard drive tightly. If not, the hard drive will be damaged due to the vibration which might lead to the data loss.

6. Install the connector back to the back side of hard drive case. Then the SATA hard drive is installed into the hard drive case.

Step 2, Connecting to power supply

1. Prepare the fuse: Cut off the red ring and insert a piece of fuse into the fuse box.





2. Connect the fuse to the yellow and red wire of the power cable, then connect the power cable to positive pole of the battery. Connect the black wire to the minus pole of the battery. **PLEASE NOTE THAT, THE FUSE IS USED TO PROTECT THE BATTERY FROM SHORTCUT ON THE WIRE, SO THE FUSE SHOULD BE VERY CLOSED TO THE BATTERY. CONNECT DIRECTLY TO THE BATTERY IS RECOMMENDED.**



Notice

1. The DVR uses DC power input, please be very careful when connecting to the "+" and "-" of the power supply.
2. Wide voltage range of 8V-32V for the DVR. The DVR may be damaged if the voltage comes too high. And the DVR may not work if the voltage comes too low.
3. Power of the DVR should be supplied by the car battery.
4. Power consumption of the DVR can be 60W when the engine starts. All the cables for connecting from power to the DVR should be thick enough for current over 5 Amperes.
5. To protect the battery from being damaged of short circuit on the cable, the fuse should be placed very closed to the car battery.

Step 3, Connecting to camera

Step 4, Turn on the recorder

Insert hard drive into the DVR, use key to turn on the DVR.

Step 5, Format the hard drive

You need to format the hard drive if it is used in the DVR for the first time. Choose the menu item "16 Format" to format the hard drive.



There are two different options for file system, "MPFS" and "MPFS/FAT32". The MPFS (Multiple Protect File System) is specially designed for the mobile application. The "MPFS/FAT32" has all of the features of MPFS and it is also compatible with the FAT32. If you need to use the Microsoft Windows or other systems that support FAT32 to read the file directly from the hard drive, please choose "MPFS/FAT32".

Step 6, Choose video quality

Choose menu item "03 Video Quality" to set the video quality.



The detailed parameters of image quality are listed in following table. Please note that users can specify their own setting in "Custom" quality.

Quality	Resolution	Audio Channels	Video Bit rate （Bit/s）	Audio Bit rate （Bit/s）	Disk Capacity
Default1	352×258	2	1152K	224K	604M/Hour
Default2	480×576	2	2400K	224K	1153M/Hour
Default3	704×576	2	3000K	224K	1416M/Hour
Default4	704×576	2	4000K	224K	1856 M/Hour
Custom	Specified by user	2	Specified by user	Specified by user	Specified by user

Step 7, Record to hard drive

Press REC button on the remote to start recording on the hard drive. You can see a red dot on the top left corner of the screen to indicate the recording.

Step 8, Install the monuting bracket

1. Release the screws at the front of DVR and take the DVR out of the mounting bracket.

2. Use screws to install the mounting bracket.



3. Install the DVR back to the mounting bracket. Please note, there is a lock connector at the bottom side of DVR. Please make sure this connector is in position when you put the DVR back to the mounting bracket.

4. Use the screws to install the DVR to the mounting bracket.

Play back recorded file on Hard Drive

1. To play back the files on hard drive, press PLAY button on the remote, you will see following information on the screen.

2. Choose "DISK1", then you can see the root directory of the hard drive.



3. Choose "RECORD" directory, you will see a list of dates.



4. Choose date, you will see a list of all files recorded on the specified date.



5. Select a file and press "Open" to play back.



How to copy from Hard Drive to Compact Flash

1.To copy the whole file from hard drive to CF card, press play button on the remote and choose the file you want to copy, then choose **"Copy"**, you can copy from hard drive to the **"Vault"** directory of the Compact Flash.



2. To copy part of the file. Please play the file first, when the playing back get to the start position you want to backup, please press * on the remote to mark the start position of the clip, then you can press # on the remote to mark the end position of the file you want to backup, then the mobile DVR will display a dialog to prompt you to start coping file.



Please note, if you do not insert CF card into the mobile DVR, those process will copy the file to the "Vault" directory of the hard drive other than CF card.

Record to Compact Flash

1. Insert the Compact Flash into the DVR.
2. Format the Compact Flash if it is the first time recognized by the DVR. Choose menu item **"17 Format"** and then choose the **"Drive"** to be **"CF1"**.



3. Set up the DVR to record to Compact Flash. Choose menu item **"02 Record Setup"** and select CF record **"Type"** to be **"Continuous"**



4. Press REC on remote controller to start recording on Compact Flash. If there is no Hard Drive in the DVR, it will record to Compact Flash only; but if you install a Hard Drive in the meantime, it will record to both of Compact Flash and Hard Drive. You will see two red dots on the screen.

Using the Menu

1. Press MENU on the remote controller, the main menu will show up.



2. Press ▲ or ▼ key to go up and down in the main menu. There are multiple screens in the main menu. You can also press the key number on the remote controller to directly locate the menu item. For example, to FORMAT a hard drive, press digits 1 and 7 on the remote controller to go to the menu item No. 17, "17 FORMAT"



3. Press MENU or OK to select the menu option. For example, if you choose **"17 FORMAT"**, the following dialog will show up. Use ▲ or ▼ key to select different dialog item in the dialog. Use > or < key to choose different option in the dialog item. For example, you can use ▲ or ▼ key to select among the **"Drive"**, **"File System"**, **"OK"**, **"Cancel"** dialog items in the "format" dialog. If you select the **"File System"** dialog item, you can use > and < key to select between **"MPFS"** and **"MPFS/FAT32"** options.



Using Alarm and Sensor

The Mobile DVR can be connected to 4 alarms and 6 sensors. All these alarms and sensors can trigger the alarm recording. They can also turn on the buzzer, trigger the alarm out, trigger to toggle video display, and trigger to show information on the screen.

Here are the pictures for alarm connector and sensor connector.



ALARM



SENSOR

LABEL	Color	Description
AO1	Red	Alarm output 1, B pole
AO1	Brown	Alarm output 1, A pole
AO2	Red	Alarm output 2, B pole
AO2	Orange	Alarm output 2, A pole
SENSOR	Black	Sensor 1
SENSOR	Brown	Sensor 2
SENSOR	Red	Sensor 3
SENSOR	Orange	Sensor 4
SENSOR	Yellow	Sensor 5
SENSOR	Green	Sensor 6
SENSOR	Blue	Speed sensor
ALARM	Black	Alarm 1
ALARM	Brown	Alarm 2
ALARM	Red	Alarm 3
ALARM	Orange	Alarm 4

For more detailed information on how to use alarm, we will take an application that using a panic button to trigger the alarm 1 as an example. In this application, we will use a panic button to connect to alarm 1 and connect an alarm bell to the alarm out 1 of DVR. Once the panic button is pressed, the recorder will turn on the alarm bell, show "PANC" on the

screen and start recording.

1. Connect the panic button and alarm bell to the DVR. Please see the following diagram; the panic button is connected to alarm 1. Once the panic button is pressed, alarm 1 is connected to the high level (+12V) and it will be triggered.



2. Setup the alarm action. Select menu item "06 Alarm Action", then choose "Alarm Input 1", then you can set up the action need to be done once the alarm is triggered. In this application, firstly we need to set the "Alarm Record" to be "On", thus the DVR will start recording once the alarm 1 is triggered. Secondly we need to set "Alarm Out 1" to be "On", so that if the alarm 1 is triggered, the "Alarm Out 1" will act to turn on the bell. At last, we will set the "Information" to be "PANC", so the "PANC" will be showed on the screen indicating that the panic button is pressed. And please also note that the "Level" is set to "HIGH", which means the "Alarm Input 1" will be enabled if it was connected to the HIGH level (+12V), this is what we are doing for this application. If you need the "Alarm Input 1" to be triggered by LOW level (GND), you should set this to be "LOW".



3. Then you can press the panic button. Once the panic button is pressed, the DVR will start recording, show "PANC" on the screen and turn on the alarm bell. If the panic button is released, the DVR will stop recording, clear "PANC" on the screen and turn off the alarm bell.

Using Pre and Post Recording

The DVR can record in pre and post alarm recording mode. In this mode, the DVR will keep the recording before and after the time when the alarm is triggered into a complete footage.



To set up Pre and Post recording, choose menu item "05 Alarm Setup", then set up the "Pre" and "Dwell" time for recording. For "Pre" and "Dwell" setting, the first edit box is in minutes and the second is in seconds. The maxiam number for "Pre" and "Dwell" setting is 99 minutes and 59 seconds. The following setting shows pre-recording time is 1 minute and 30 seconds and the post-recording time is 10 minutes.



To make DVR going to pre-recording mode, please press ALARM button on the remote. The DVR will start recording continuously first, once it reaches the time for pre-alarm recording, the DVR will be in pre-alarm recording mode. The DVR will show a yellow dot on the screen to indicate that DVR is in pre-alarm recording mode.

Record to hard drive continuously and record to Compact Flash in alarm mode

1. Install the hard drive and Compact Flash inside the DVR.
2. Choose the menu item **"02 Record Setup"** and select CF record **"Type"** to be **"ALARM"**.



3. Set up the alarm and sensor that will trigger alarm recording. Please refer to chapter **"Using Alarm And Sensor"**.
4. Set up pre and post recording time if you need this function. Please refer to chapter **"Using Pre and Post Recording"**.
5. Press REC button on the remote. The DVR will record to hard drive continuously and record Compact Flash in alarm mode.

Schedule the recording

To schedule the recording for DVR, you need to set up the schedule item and add the item into the schedule list. Totally the DVR support 10 schedule items.

Start recording when unit is powered on

1. To make DVR start recording immediately after the unit is turned on, please choose menu item "04 Schedule Record".



2. Choose **"New Item"**, select **"Power On"** for **"Mode"** and select **"Continuous"** for **"Type".** Thus the DVR will start recording continuously while powered on. If you need DVR to start alarm recording while powered on, you can select **"Alarm"** for **"Type"**.



3. Press OK to add this item to the DVR. Once this item is added into the schedule list, the DVR will start recording every time the unit is turned on.



Start and Stop recording at a specified time every day

1. To make DVR to record at specified time every day, please choose menu item "04 Schedule Record".



2. Choose **"New Item"**, select **"Daily"** for **"Mode"** and select **"Continuous"** for **"Type".** Then set up the time for start and stop recording in "Period". As following diagram shows, the DVR will start recording at 8:00 and stop recording at 18:00 every day.



3. Press OK to add this item to the DVR.



Start and Stop recording at a specified date weekly

1. To make DVR to record at specified day in a week please choose menu item "04 Schedule Record".



2. Choose **"New Item"**, select the day from MON(Monday) to SUN(Sunday) for **"Mode"** and select **"Continuous"** for **"Type".** Then set up the time for start and stop recording in "Period".



3. Press OK to add this item to the DVR. The DVR will start recording at 8:00 and stop recording at 18:00 every Monday.



Vehicle Setup

Set the vehicle ID and route information

1. Choose menu item **"10 Vehicle Setup"**, set the **"Car ID"** and **"Route"** information.



2. The Car ID and the route information will be displayed on the top left part of screen.

Get speed from GPS

1. Connect the GPS receiver with DVR. The GPS should connect to the **"R1"** connector of DVR.



2. Choose menu item **"10 Vehicle Setup"**, then choose the **"Speed"** to be **"From GPS"**.



3. The speed will be displayed on the right bottom of the screen. If you need the speed to be "MPH" other than "KM/H", please select **"mile"** in the **"Pulse No."**.

Get Speed from Speedometer

1. Connect the speed sensor input wire on the DVR to the speed sensor. The speed sensor input wire of the DVR is the blue wire on the jet marked with "SENSOR".

Speed sensor input wire on DVR:



Label	Color	Description
SENSOR	Blue	Speed sensor input

Following is a picture of a speed sensor.



If the speedometer already has signal output (showed as SIG output in the following diagram) wire, you can connect "Speed sensor input" wire to the SIG output wire directly.



If the speedometer will not have signal output, we need to connect to the output of speed sensor. This could also be the input of the speedometer.



2. Set the DVR to get speed from speedometer.



3. Calculate the pulse number the speed sensor generates for one kilometer. Usually the speed sensor will generate 8 or 16 pulses if the wheel goes one round and you need to calculate the number of the pulse that the speed sensor will generate if the car runs for one kilometer. Then set the number to **"Pulse No."**.

While in a real application, it's not easy to pulse number by the calculation on the paper. In this case, you can choose the menu item **"10 Vehicle Setup"**, then set the **"Pulse No."** to be **"0"**. Then you drive the car for one kilometer. The number in the **"Pulse No."** will increase as you are driving. The number showed in the **"Pulse No."** once you get to one kilometer would be the number you need.

Manage the power

Use the ignition to control the power

1. Connect the ignition to the yellow wire of the power cable. And connect the red and black wire to the "+" and "-" pole of battery.



2. Set **"Power Off Delay"**. Select menu item **"12 Power Management"**, then set the **"Power Off Delay"**. As the following diagram shows, the **"Power Off Delay"** is set to 1800 seconds(30 minutes), which means the DVR will be turned on once the ignition is on and it will be turned off 30 minutes after the ignition is off. The maxim number of the **"Power Off Delay"** is 65535 seconds (18 hours, 12 minutes and 15 seconds). If the **"Power Off Delay"** is set to zero, the DVR will be turned off immediately after the ignition is off.



3. If the ignition level is LOW when the ignition is turned on, you need to set the **"Ignition Level"** to **"LOW"**.

Turn on/off the DVR automatically

1. Connect the DVR to the battery. Please note that you need to connect the yellow wire (ignition wire) to the "+" pole (+12V or +24V) of the battery.





2. Set the time for "Power On" and "Power Off". As showed in the following diagram, the DVR will be turned on at 8:00 and turned off at 20:00.



Set Date and Time

1. To set the time of DVR, please choose menu item **"13 Set Time"** to set the date and time of DVR. The DVR support 3 type of format for displaying the date, **"YYMMDD"** (Year-Month-Date), **"MMDDYY"** (Month-Date-Year) and **"DDMMYY"** (Date-Month-Year). You can choose the format you need in the **"Format"**.



2. The DVR supports two DST (Daylight Saving Time) modes, the **"Europe"** type and **"USA"** type. You can choose the type you need in **"DST"**. If you select **"Europe"** type for **"DST"**, you also need to set your **"Time Zone"** as the Europe DST based on the UTC time.
For **"Europe"** type, DST will start at 1:00 am UTC on last Sunday in March and end at 1:00 am UTC on last Sunday in October. For **"USA"** type, DST will start at 2:00 am local time on the second Sunday in March and stop at 2:00 am local time on the first Sunday of November.
3. The DVR can synchronize the time to the GPS receiver. To do this, connect to the GPS receiver first, then set the **"GPS Syn"** to **"On"**.

Using Pan/Tilt/Zoom

1. Connect the DVR to Pan/Tilt/Zoom through RS485 connector.



2. Choose menu item "14 PTZ Config", set the "Protocol", "Baudrate" and horizontal speed and vertical speed. .



3. Control the Pan/Tilt/Zoom: Press ESC to exit the main menu, then presses OK button on the remote controller to enter the PTZ control state. You can use the keys in the following table to control the PTZ.

KEY	FUNCTION
Number 1~9	Select the camera number
UP, DOWN, LEFT, RIGHT	Move the camera
NEXT, PREVIOUS	Zoom In/ Out
Fast Forward, Fast Backward	Focus
PAUSE, VIDEO	Iris Far/Near
AUDIO	Start/Stop auto scan
RECORD	Set the preset
PLAY	Get the preset

Manage the configuration

Export the configuration

You can export the setting of DVR to a file on the hard drive. This could be useful if you need to set many DVR to the same configuration. To export the configuration, choose menu item **"18 Export Configuration"**, and then choose "OK" to confirm this operation. You will find a file named "MDR.CFG" in the hard drive. If you open this file in a different DVR, the DVR will have the same setting saved in the "MDR.CFG".



Reset Defaults

To set the DVR to have default settings, choose menu item **"19 Reset Defaults"**, then choose "OK" to confirm the operation. Please note some settings need to restart the DVR to take effect.

Update the firmware

To update the firmware of the DVR,

1. Copy the firmware file to the hard drive. The firmware file is a file whose postfix is MIC (.mic). You can copy this file to the hard drive using either of the following ways. You can use the USB reader to copy the file from your PC to the hard drive.
2. Open the firmware file to update the mobile DVR. Press PLAY button on the remote and choose the firmware file you copied to the hard drive and "OPEN" it.



3. Restart the mobile DVR to using the new firmware.

PLEASE NOTE: Do NOT turn off the power while updating!!!

Using GPRS

This part is only applicable for models that support GPRS. The DVR supports quad band(850/900/1800/1900 MHz).
1. Connect the DVR with GPRS antenna.

2. Install the SIM card into the DVR.

Following is the steps of installing the SIM card to ZDDV-C304
Step1, Use ballpen or other tools with sharp end to eject the SIM card tray.

Setp 2, put the SIM card into the SIM card tray.

Step 3, insert the SIM card tray back to the DVR.

3. Select menu item **"19 GPRS Setup"**. Set up the **"APN"** (Access Point Name). Please contact your service provider for details.
4. Set up the telephone number you need to dial for GPRS service in the **"Dial"**. This number usually start with *99. Please contact your service provider for details.

5. Set up the **"User Name"** and **"Password"** for your GPRS service. Please contact your service provider for details. Usually the **"User Name"** and **"Password"** is set to be blank.



6. Set up the **"Server"** IP address and **"Port"** number. The server IP is the IP address of the computer you are using for running the client software. And we are now using Port 8500 to Port 8509 for GPRS transmitting. Following shows Server IP is 220.231.171.34.

7. Set up the **"Compression"** rate. The compression rate defines the quality of the pictures sent through GPRS. The range of the compression rate is 25~75. The value 75 means the best quality.
8. If you are using a router to access Internet. You will also need to set Port Forwarding in your router. Please forward Port No. 8500 to Port No. 8509 to the LAN IP of your computer. We are using UDP to transmitting through GPRS, so please select Protocol Type to be "UDP".
9. If everything is OK, start your DVR and run the client software. You will be able to see the DVR on the list of the client software. For more information about the operation on client software, please see the manual of client software.

Cable Description

1, Power Input connector



PIN	Color	Description
2	Red	+12V (+24V) wire
4	Yellow	Ignition wire
6	Black	Ground wire

2, Video-audio input connector

1）Video-audio input cable



Mark	Description
VIN	Video input
AIN	Audio Input
+12V	Power output (+12 VDC, Maximum current 1A)
GND	Ground

2）Video-audio output connector



Mark	Description
VOUT	Video Output

AOUT1	L channel for audio output
AOUT2	R channel for audio output
+12V	Power output (+12 VDC, Maximum current 1A)
GND	Ground

3, J2 Cable (Integration Cable)



Pin	Connector Label	Color	Description
1	COM2		Data Receive, COM2
2	COM2		Data Transmit, COM2
3	GPS		DATA Receive, GPS
4	GPS		Data Transmit, GPS
5	(N/A)		Ground
6	GPS		+5 VDC
7	PTZ	Red	RS485, Plus Pole
8	PTZ	Black	RS485, Minus Pole
9	IR		IR connector
10	AO1	Red	Alarm output 1, B pole
11	AO1	Brown	Alarm output 1, A pole
12	AO2	Red	Alarm output 2, B pole
13	AO2	Orange	Alarm output 2, A pole
14	SENSOR	Black	Sensor 1

15	SENSOR	Brown	Sensor 2
16	SENSOR	Red	Sensor 3
17	SENSOR	Orange	Sensor 4
18	SENSOR	Yellow	Sensor 5
19	SENSOR	Green	Sensor 6
20	SENSOR	Blue	Speed sensor
21	IR		IR connector
22	ALARM	Black	Alarm 1
23	ALARM	Brown	Alarm 2
24	ALARM	Red	Alarm 3
25	ALARM	Orange	Alarm 4

4, GPS Connector (RS232 port 1)



PIN	Description
2	TXD: Data Transmit
3	RXD: Data receive
5	GND: Ground
9	+5V DC: Power output

5, COM2 Connector (RS232 port 2)



Junction	Description
2	TXD: Data Transmit
3	RXD: Data receive
5	GND: Ground

Specification

Power In	8 VDC~32 VDC
Power Out	12 VDC, Max Current 1A
Video Input	4 channels/2 channels/1 channel, 1.0Vp-p, 75Ω,BNC
Video Out	1 channel, 1.0Vp-p, 75Ω,BNC
Video Standard	PAL/ NTSC
Audio Input	2 channels/1 channel, Line In, 50~400mv, 50Hz~3500Hz
Audio Out	1 channel
Compression	MPEG2
Video Recording	MAX Resolution: 704*576,Frame Rate:25fps(PAL),30fps(NTSC)
Storage	1. Removable Hard Disk Drive (standard 2.5 inch for laptop) 2. CF Card
Alarm Input	4 Alarm Input
Alarm Output	2 Alarm Output
Ethernet	10/100M Base-T, RJ45
GPS	NMEA 183
PTZ	RS485
Language	English / Chinese
Supported Band	Quad band, 850/900/1800/1900 MHz (applicable for models that support GPRS only)
Product Size	180*180*42 mm (w/o antivibration mounting)
Weight	2.8Kgs (w/o antivibration mounting)
Power Consumption	10W (15W when with Hard Drive)
Working Condition	Temperature: 0℃~+50℃, Humidity: <90%

List of Standard Accessories

Item	Description	Quantity
1	Mobile Digital Video Recorder with antivibration mounting (cradle)	1 pc
2	Hard Drive Case (w/o Hard Drive)	1 pc
3	AV Cable	1 pc
4	J2 cable (integration cable)	1 pc
5	Remote controller	1 pc
6	Keys	2 pcs
7	Fuse box	1 pc
8	5 Amp fuse	2 pcs
9	Screw for DVR installation	4 pcs
10	Screw for fixing the hard drive	4 pcs
11	Power Cable	1 pc